

Operating instructions

Solar irrigation system "Water Drops"



influence of the weather, e.g. against too strong rain or direct spraying with the water hose.

These instructions relate **ONLY** to this product and contain important information for using the product for the first time. Please keep these instructions for later reference and should always accompany the product in the event of transference to a new user.

- Now choose a sunny, shadow-free place for the solar module. The solar module may be inserted into the ground with the ground spike or screwed on with the enclosed holder.

Customer support:

If you have problems or questions regarding this product, simply contact us!
Monday to Friday 9 am to 12 noon and 1 pm to 4 pm.
 By phone: +49 9605-92206-0
 By e-mail for ordering spare parts: ersatzteil@esotec.de
 By e-mail for questions about the product: technik@esotec.de
Product: Manufacturer Item No.: 101100

1. Introduction

Dear Customer, thank you for purchasing the solar pump kit. With this solar pump kit you purchased a product manufactured according to the current state of technology.

CE This product fulfils all requirements of the valid European and national regulations. The conformity was proved. The relevant declarations and documentation are deposited with the manufacturer.

To maintain this state and guarantee a safe operation, you as the user will have to follow this operating manual!

2. Safety Instructions



- In case of damages caused by not following this operating manual, the warranty rights will expire! We exclude liability for any consequential damages!
- We exclude liability for property or personal damages caused by inappropriate handling or not following the safety instructions.
- In these cases any guarantee rights will expire.

Due to safety and admission reasons (CE) it is not allowed to arbitrarily reconstruct and/or change the solar pump kit.

Therefore, please keep to the operating manual.

The accident prevention rules of the association of the industrial trade cooperative association for electric plants and working material are to be considered in industrial environments.

3. Function and intended use

The solar irrigation system is intended for outdoor use. With this system it is possible to irrigate the plants in the garden, in the greenhouse, in the hotbed, on the balcony or on the raised bed with a maximum of 15 water drippers. The irrigation is performed once a day at the break of dawn and once at nightfall. The operating time of the pump may be set between 0.5 minutes and 12 minutes. The dripping volume is fixed to 2 l/h.

Thus, you have the ideal solution for an automatic and network-independent irrigation of your potted plants or vegetable bed. The integrated diaphragm pump sucks water from a depth of up to 2 meters e.g. from a rainwater barrel. The crystalline solar module charges the integrated battery pack during the day and sunshine.

The means complete independence from the mains current!


4. Scope of delivery

- 1 x control unit
- 1 x solar module including connecting cable and holder
- 1 x Float switch
- 2 m suction hose with filter transparent
- 5 m pressure hose black
- 1 x T-piece transparent
- 15 x T-piece small black
- 15 x hose holder
- 15 x water dripper 2 l/h
10. valve
1. seal plug




5. Assembly and putting into operation

- Please carefully take all parts out of the package. Make sure that you have really taken all parts out of the package before disposing the package materials in an environmentally compatible way.
- Choose an appropriate location for the control unit. In doing so, please pay attention to the fact that its position has to be higher than the maximum water level of the water reservoir. Protect the control unit against the direct




- Lay the cable for the solar module carefully and without tripping hazards. Connect the plug of the cable on the solar module with the associated socket on the control unit (1). The integrated battery is charged in case of adequately intensive solar radiation onto the solar module.
- Remove the 2 protective caps from both nozzles for inflowing and outflowing water.
- Cut off approx. 20 centimeters from the (transparent) suction hose (2) and attach this short piece onto the nozzle for outflowing water. (2).
- In this short piece of hose, please insert the T-reducer with its larger side (3).
- On the nozzle for inflowing water, please attach the remaining (transparent) suction hose auf (4). This hose has to be laid up to the reservoir tank for water, e.g. a rainwater barrel (5).
- Insert the suction filter (if not already assembled) onto the suction hose (6). This filter keeps coarse dirt away from the pump. Throw this filter into the filled water barrel (7).
- Now take the black float switch and also put it into the filled water barrel (7). Now insert the plug of the float cable into the socket on the control unit (8). The pump is working if the float is upright in the water. In case it should lay on its side due to the lack of water, then the pump will be deactivated and it is required to refill an adequate amount of water.
- Cut off approx. 10 centimeters from the (black) irrigation hose and insert this short piece onto the free end of the T-reducer (9) which points upwards. In this short piece, please insert the (blue) ventilation valve (10). This valve prevents the uncontrolled running on of the water.



Note: Here, please make sure that the valve is inserted with the right side up!

- With the remaining piece of the irrigation hose, the 15 hose holders (11), the 15 black T-pieces (12) and the 15 water drippers (13) you are now able to install the desired distribution grid for the irrigation. The dripping volume is fixed to 2 l/h.




- With the multistage selector switch (14) on the housing you may set the time of operation of the pump. The pump pumps at the break of dawn and at nightfall depending on the set value. It may be selected in 6 stages in a range of 30 seconds (0.5 min) up to a maximum of 12 minutes. In the position „Test“ it is possible to test the pump or pump the air out of the hoses when the pump is put into operation for the first time.



14. As soon as everything is assembled, please put the selector switch to the position „Test“. The pump will then start to work if the battery is charged sufficiently. The pump sucks in the water autonomously. In doing so, make sure that the filter of suction hose is below the water surface.
15. Now move the controller on the control unit to the desired pumping time.
The solar irrigation system is now ready for use!

Not required parts may be stored in the drawer in the control unit and taken out if needed.

6. The control unit



1. Rotary switch position

Test
Off

0.5 – 12 min/12h

Function

Test function and for the initial putting into operation

Switched off, but the battery is charged via the solar module.

The pump pumps at the break of dawn and at nightfall depending on the set time.

2. LED display „Pump on“

green:
flashing red:
flashing red/green:

Meaning

pump is working
not enough water in the rain barrel
not enough water in the rain barrel and the integrated battery is discharged

3. Connection for the float switch

4. Connection for the solar module

7. Exchange of battery

1. To exchange the battery, please switch the rotary switch to the position „Off“.
2. Unscrew the 5 screws on the back side of the control unit and remove the cover.
3. Disconnect the battery and remove it from the holder.
4. Now insert an identical in construction battery pack with 3.6 V and a minimum of 1200 mAh (esotec spare part No.: 901021 „www.esotec.de“).
5. Close the cover and screw in the 5 screws.
6. Put the rotary switch into the desired position
7. The solar irrigation system is now ready for operation again.

Note: Used batteries have to be disposed of in an environmentally sound way and do not belong into the household waste. Your dealer is required by law to take back our old batteries.

Battery take-back

- Batteries must not be discarded into domestic waste.
- The consumer is legally required to return batteries after use, e.g. to public collecting centers or to battery distributors.
- Contaminant-containing batteries are labeled with the sign „crossed-out trashcan“ and one of the chemical symbols. Used batteries should be disposed environmentally friendly and should not be discarded into domestic waste. Your dealer is legally required to take back old batteries.



NiMh

8. Care and maintenance

Occasionally wipe the solar module with the soft and slightly wet cloth. The suction filter has to be washed out depending on the contamination.

9. Technical data

- solar module nominal power: 0.7 Wp
- max. water delivery volume: 36 l/h
- Volume each water dripper: 2 l/h
- battery pack: NiMh 3,6 V/ 1200 mAh
- protection class: III
- protection type: IP 44

The battery pack has to be exchanged at the latest every 2 years!

For spare parts available for this system, please see under www.esotec.de

Note: Protect the pump against frost!

The system has to be dismantled in the cold winter months and stored in a warm place!

10. Safety Instructions:

DANGER for children! Keep children away from swallowable small parts (ascending pipe and sprinklers) and the packaging material. Danger of suffocation!

WARNING: risk of stumbling! Lay the connecting cable so that it will not become a trip hazard!

CAUTION Material damage! When setting up the solar module without module bracket, please pay attention to an adequate stability. The solar module may be damaged in case of tipping or in case of an impact of a foreign object.

Disposal instruction for electric appliances:

Dear customer, if you want to get rid of the article, please dispose it according to the current regulations. The municipal authority will provide you with information.



Rechargeable battery notes

- Rechargeable batteries should not be played with by children. Never leave rechargeable batteries lying around; they could be swallowed by children or pets.
- Rechargeable batteries must never be short-circuited, disassembled or thrown into fire. This leads to a danger of explosion!
- Leaking or damaged rechargeable batteries can cause chemical burns when they come into contact with skin. For this reason, please make use of suitable protective gloves.
- Rechargeable batteries should only be replaced by structurally identical rechargeable batteries from the same manufacturer. Normal batteries must not be used since these are not rechargeable.
- Make sure the rechargeable batteries are inserted with the correct polarity.
- For long periods of time of non-use (for example, storage), remove the inserted rechargeable batteries to avoid damages via the leaking rechargeable batteries.

